




PLUTONE 30 CE tav.unica**Riferii Nome prodotto****Codice**

1	WIRE WHIP	PLT 30LT	CNP30-42402300
2	BEATER	PLT 30LT	CNP30-42402100
3	HOOK	PLT 30LT	CNP30-42402200
4	AIRING BOARD	PLT 30LT	CNP30-50405220
5	MACHINE BODY	PLT 30LT	CNP30-42401509
6	SIDE BUFFLE PLATE	PLT 30LT	CNP30-50405257
7	LOCATING PIECE FOR GRID	PLT 30LT	CNP30-50405320
8	STAILESS STEEL RING	PLT 30LT	CNP30-50307014
9	BOLT	PLT 30LT	CNP30-50405177
10	LOCATING PIN FOR BOWL	PLT 30LT	CNP30-42401100
11	STAILESS STEEL RING	PLT 30LT	CNP30-50308013
12	STAILESS STEEL NUT	PLT 30LT	CNP30-50304044
13	KEY	PLT 30LT	CNP30-50313025
14	KEY	PLT 30LT	CNP30-50313021
15	MAIN SHAFT	PLT 30LT	CNP30-40701300
16	KEY	PLT 30LT	CNP30-50313027
17	OIL SEAL	PLT 30LT	CNP30-50310015
18	PLUG ATTACHMENT HUB	PLT 30LT	CNP30-50405015
19	RUBBER SEAL 55X5G	PLT 30LT	CNP30-50399041
20	BOLT M6X20	PLT 30LT	CNP30-50303080
21	SPRING	PLT 30LT	CNP30-50405065
22	SPRING WASHERS	PLT 30LT	CNP30-50308005
23	SHAFT END RING	PLT 30LT	CNP30-50405035
24	BEARING 6204	PLT 30LT	CNP30-50301006
25	SPACER-LOWER	PLT 30LT	CNP30-40701200
26	BOLT M8X20	PLT 30LT	CNP30-50303019
27	CROSS PAN HEAD SCREW	PLT 30LT	CNP30-50305023
28-2	GEAR	PLT 30LT	CNP30-40701600
28-4	ROLLER	PLT 30LT	CNP30-50306040
28-3	SPRING	PLT 30LT	CNP30-608032
28-1	SUPER MACHINE PARTS	PLT 30LT	CNP30-40701500
29	GEAR	PLT 30LT	CNP30-50405169
30	GEAR	PLT 30LT	CNP30-40701700
31	BUSHING	PLT 30LT	CNP30-50405041
32	SLEEVE	PLT 30LT	CNP30-40702000
33	BUSHING	PLT 30LT	CNP30-50405042
34	GEAR	PLT 30LT	CNP30-40702100
35	GASKET	PLT 30LT	CNP30-40702200
36	BEARING 6202	PLT 30LT	CNP30-50301008
37	BUSHING	PLT 30LT	CNP30-40702300
38	ATTACHMENT HUB	PLT 30LT	CNP30-42402600
39	PAPER RING	PLT 30LT	CNP30-608034
40	CIRCLIPS	PLT 30LT	CNP30-50405026
41	GEAR	PLT 30LT	CNP30-50405170
42	CIRCLIPS FOR SHAFT 18	PLT 30LT	CNP30-50312007
43	PLANET GEAR	PLT 30LT	CNP30-40702600
44	WORKING SHAFT	PLT 30LT	CNP30-42400200

45	BEARING 6205	PLT 30LT	CNP30-50301007
46	OIL SEAL 28X52X7	PLT 30LT	CNP30-50310009
47	FIXING DIVICE	PLT 30LT	CNP30-42401600
48	BOWL HOLD KITS	PLT 30LT	CNP30-40703500
49	LOCATING PIECE FOR GRID	PLT 30LT	CNP30-50405319
50	POSITION SWITCH D4C	PLT 30LT	CNP30-50506087
52	STICK	PLT 30LT	CNP30-50402200
53	BRAND	PLT 30LT	CNP30-50402196
54	POWER INDICATOR	PLT 30LT	CNP30-50506081
55	KEY 6X25	PLT 30LT	CNP30-50313022
56	INTERNAL GEAR	PLT 30LT	CNP30-40702400
57	OPERATING SHELF	PLT 30LT	CNP30-40702700
58	PIN 4X30	PLT 30LT	CNP30-50306003
59	CAM-GEAR SHIFTER	PLT 30LT	CNP30-40502900
60	HANGER	PLT 30LT	CNP30-40706409
61	SPRING	PLT 30LT	CNP30-50406006
62	UNDER MASK	PLT 30LT	CNP30-50405260
63	SUPPORT	PLT 30LT	CNP30-42400500
64	UPPER MASK	PLT 30LT	CNP30-50405258
65	BOWL HOLD KITS	PLT 30LT	CNP30-40703500
66	DISTANCE SWITCH	PLT 30LT	CNP30-50506058
67	OVERLOAD SWITCH	PLT 30LT	CNP30-50503009
68	NUT M8	PLT 30LT	CNP30-50304005
69	TIMER	PLT 30LT	CNP30-50504003
70	WATERPROOF JOINT	PLT 30LT	CNP30-50514012
71	LIFTING PLATE	PLT 30LT	CNP30-50405282
72	HANGER	PLT 30LT	CNP30-40706409
73	RED BUTTON	PLT 30LT	CNP30-50506029
74	CONNECTING ROD	PLT 30LT	CNP30-42401000
75	PIN 5X40	PLT 30LT	CNP30-50306007
76	HANDLE-SHIFTER	PLT 30LT	CNP30-42400800
77	GREEN BUTTON	PLT 30LT	CNP30-50506026
78	RED BUTTON	PLT 30LT	CNP30-50506011
78	RED BUTTON	PLT 30LT	CNP30-50506006
79	BOLT 6X10	PLT 30LT	CNP30-50303154
80	SPACER	PLT 30LT	CNP30-50307008
81	SPRING	PLT 30LT	CNP30-50406022
82	BACK COVER BOARD	PLT 30LT	CNP30-50405251
83	NUT	PLT 30LT	CNP30-50304007
84	CRANK LEVER	PLT 30LT	CNP30-40705509
85	TIMER KNOB	PLT 30LT	CNP30-50506041
86	PIN 4X25	PLT 30LT	CNP30-50306002
87	BOLT M8X40	PLT 30LT	CNP30-50303024
88	SPACER 12	PLT 30LT	CNP30-50307007
89	FLAT VALVE CAP	PLT 30LT	CNP30-50405032
90	TOP BATTER VALVE CAP	PLT 30LT	CNP30-40701100
91	RING	PLT 30LT	CNP30-50308004
92	GEAR	PLT 30LT	CNP30-40700800
93	SCREW	PLT 30LT	CNP30-50405064
94	SPRING PLT30		CNP30-50406021

95	SHIFTING YOKE	PLT 30LT	CNP30-40703400
96	CROSS PAN HEAD SCREW M5X1	PLT 30LT	CNP30-50305015
97	TAPER PIN 6X20	PLT 30LT	CNP30-50306022
98	TRANSMISSION SHAFT SUPPORT	PLT 30LT	CNP30-40700500
99	DECLUTCH SHIFT SHAFT	PLT 30LT	CNP30-40703600
100	SHIFTING YOKE	PLT 30LT	CNP30-40703400
101	RING 10	PLT 30LT	CNP30-50308006
102	NUT M10	PLT 30LT	CNP30-50304006
104	SPRING	PLT 30LT	CNP30-50406004
105	BOLT M8X30	PLT 30LT	CNP30-50303087
106	SPEED HANDLE	PLT 30LT	CNP30-42402500
107	RING	PLT 30LT	CNP30-50405036
108	NUT M18X1.5	PLT 30LT	CNP30-50304012
109	CIRCLIPS FOR SHAFT 17	PLT 30LT	CNP30-50312005
110	PLUG 1	PLT 30LT	CNP30-40703000
111	WORM WHEEL	PLT 30LT	CNP30-50405025
112	PLATE-SHIFTER INDEX	PLT 30LT	CNP30-42400300
113	PIN	PLT 30LT	CNP30-50306061
114	RING 40	PLT 30LT	CNP30-50312026
115	BOLT M5X14	PLT 30LT	CNP30-50303003
116	RING	PLT 30LT	CNP30-50308003
117	RING	PLT 30LT	CNP30-50405034
118	BEARING 6203	PLT 30LT	CNP30-50301005
119	GEAR SHAFT	PLT 30LT	CNP30-40700900
120	KEY 5X16	PLT 30LT	CNP30-50313016
121	BUSHING	PLT 30LT	CNP30-40703200
122	GEAR	PLT 30LT	CNP30-40702900
123	GASKET	PLT 30LT	CNP30-40703100
124	GEAR	PLT 30LT	CNP30-40700700
125	CIRCLIPS FOR SHAFT 20	PLT 30LT	CNP30-50312008
126	RING 35	PLT 30LT	CNP30-50312024
127	RING	PLT 30LT	CNP30-50308007
128	SHAFT WORM GEAR	PLT 30LT	CNP30-40700600
129	BEARING	PLT 30LT	CNP30-50301004
130	CIRCLIPS FOR SHAFT	PLT 30LT	CNP30-50312003
131	PLUG 2	PLT 30LT	CNP30-40703300
132	MOTOR	PLT 30LT	CNP30-50501143
133	PIN	PLT 30LT	CNP30-50306009
134	OIL SEAL	PLT 30LT	CNP30-50310002
135	FRONT HOUSING	PLT 30LT	CNP30-42400100
136	STEEL BALL 6	PLT 30LT	CNP30-50399006
137	HANDLE-SHIFTER	PLT 30LT	CNP30-42400400
138	BOLT M5X12	PLT 30LT	CNP30-50305014
139	CONNECTING ROD	PLT 30LT	CNP30-42402700
140	BOLT M5X50	PLT 30LT	CNP30-50305141
141	HANDLE COVER	PLT 30LT	CNP30-50399037
142	TOP COVER	PLT 30LT	CNP30-50403019
143	SAFETY GUARD	PLT 30LT	CNP30-42400600
144	BOWL	PLT 30LT	CNP30-50401008
145	START CAPACITOR 35MF	PLT 30LT	CNP30-50505012

146	WORK CAPACITOR 200MF	PLT 30LT	CNP30-50505005
147	CONTACT SWITCH	PLT 30LT	CNP30-50502014